



Philadelphia Scientific[®]
Water Injector *Spider* System[™]

Installation & Operating Instructions

What does a Water Injector Spider System™ include? Solar Barret One Injector Spider valve per cell. Manifold(s*)





Tubing Collars (on the thick tubing) and Ratchet Clamps. Either can be used to secure tubing to the manifold.

Tubing Plugs (if applicable)





Clear PVC Tubing (one foot of tubing per cell)

*(if applicable)




HEALTH AND SAFETY PRECAUTIONS





Batteries contain sulphuric acid, always wear approved protective clothing (gloves, goggles and apron).

The following are example installations.




Example 12-Cell Layout






Example 18-Cell Layout




Example 24-Cell Layout

Installation



Install and secure the manifold(s) to inter-cell connector(s). Trim any excess cable tie.



If the system has more than one manifold, the manifolds must all be connected to the input assembly. Push the tubing over the barb.

Note: There can never be more than four manifolds connected to a single input!




Use the black clamp to secure the tubing to the manifold

or

Slide the tubing collar over the barbed fitting and use the Collar Tool (PN# INJ-601) to secure.


Installation (continued) Remove the vent caps Snap the Injector Spider Valves into each vent opening and orient them toward the manifolds. Insert the 1/4 inch (6.3mm) tubing into the manifold. Ensure the end of the tubing is cut squarely.


Installation (continued)



Lay the tubing on top of the valve and mark the tubing where it comes over top of the tubing port . This will give a length of tubing that will fully engage the o-rings when installed correctly.


Do not run tubing under inter-cell connectors.






Be sure the tubing is COMPLETELY inserted. 5/8 inch (15.8 mm) of tubing is inserted into the gripper. This is represented by the distance between the lines on the tubing.

Installation (continued)



Repeat until all of the valves are connected to the manifold ports. If all of the ports in the manifold are not used, use tubing plugs in unused ports (e.g. 20-cell kits)



After all cells are connected, review the layout to insure that all of the valves are connected to the manifold(s) and that normal battery operations will not affect the system.

Operation:




Only use a Factory Authorized Water Supply or if not the Water Source must be qualified with a Flow-Checker (PN# INJ-FC)



Connect the Instant Valve Pro™ to the quick connect on the tubing of the Water Injector Spider System installed on the battery.

Squeeze the lever completely to fill the battery. **Do Not Partially Squeeze the Lever.**





Release the lever and then disconnect the Instant Valve Pro from the Water Injector Spider System.

Factory Authorized Water Supplies for the Water Injector Spider System™



© 2022 Philadelphia Scientific LLC. All Rights Reserved. Philadelphia Scientific and the PS logo are registered trademarks of Philadelphia Scientific. Water Injector System, Water Injector Spider System, HydroCart Smart Blinky Remote and Instant Valve Pro are trademarks of Philadelphia Scientific LLC. E&O.E.



Philadelphia Scientific LLC. 207 Progress Drive Montgomeryville, PA 18936 P: 215.616.0390 F: 215.616.0500 www.phlsci.com

PAKA205 Rev 12/2022